

Safe·mate[®]

**SM-014 Override Rod Extension Kit
For Invacare SX5 High Back Chair**

Install extension assemblies on override lever rods prior to mounting rod/handles to chair back.

Grasp override lever rod with pliers just above threads and tighten extension assembly firmly to override rod using 5/16" or adjustable wrench.

