

**Tools Required: Phillips Screwdriver and 3/8" (or adjustable) wrench**

1. Remove top upholstery screw and washer from both sides of seat back.
2. Position Base Plates below factory installed hand grips and reinstall upholstery screws. Snug but do not tighten.
3. Position Hand Grip Extensions above factory installed hand grip aligning with base plate and install 1 1/4" screws and lock nuts. Snug but do not tighten.
4. Tighten top upholstery screws on both sides.
5. Tighten all 1 1/4" screws and lock nuts. Adjust screws as needed to achieve parallel alignment with factory installed hand grips.

